

# HOW TO...

## CLEAN & DISINFECT UNICATION PRODUCTS

### CLEANING INSTRUCTIONS:

- 1. PREPARE:** Before beginning, turn device power off and unplug from all external power sources.
- 2. DISINFECT & SANITIZE:** First, gently wipe all exterior surfaces of your device using a Clorox/Lysol Disinfecting Wipe or 70% isopropyl alcohol wipe.
- 3. COMPLETE:** Wipe all surfaces again with a clean damp cloth and follow by carefully drying all surfaces using a dry, soft, lint-free cloth.

### DO...



- **DO** use approved cleaning products:  
70% isopropyl alcohol wipes  
Clorox Disinfecting Wipes  
Lysol Disinfecting Wipes
- **DO** power off device and unplug from all external power sources, devices, and cables before cleaning.
- **DO** use soft non-abrasive cloth only.
- **DO** wipe surfaces with clean damp cloth after sanitizing, then dry surfaces using a clean dry cloth.

### DON'T...



- **DON'T** use harsh chemicals:  
Chlorine  
Bleach  
Undiluted chemicals/sprays
- **DON'T** spray cleaners directly onto Unication products.
- **DON'T** use harsh or undiluted chemical products such as chlorine or bleach.
- **DON'T** use wet or extremely damp wipes/clothes (squeeze to remove excess liquid before use).

WHO COVID-19 Information: <https://www.who.int/emergencies/diseases/novel-coronavirus-2019>

CDC Cleaning/Disinfecting Procedures: <https://www.cdc.gov/coronavirus/2019-ncov/prepare/cleaning-disinfection.html>

**IMPORTANT NOTICE:** The cleaners, disinfectants and processes included in this document have been approved by Unication USA, Inc. as safe for use on Unication products & accessories. Please consult the cleaning product/chemical manufacturers' label for instructions on safe and effective use, including any precautions you should take when applying the product (e.g. safety precautions, eye/skin protection, proper ventilation, etc.) and directions for proper use (e.g. concentration, application method, contact time, etc.).



Unication USA, Inc.  
Main Line: (817) 303-9320  
Email: [Info@Unication.com](mailto:Info@Unication.com)  
Website: [www.Unication.com](http://www.Unication.com)